







All empty sockets must have jump leads fitted to complete the series circuit.

